

## SMART GREEN SCREEN PAINT PRO

### APPLICATION GUIDE

### HOW TO APPLY SMART GREEN SCREEN PAINT PRO

Please follow the instructions below to ensure you apply the Green Screen Paint Pro correctly.

Smart Green Screen Paint Pro is applied in two stages, firstly two coats of the light green base paint followed by two top coats of the Smart Green Screen Paint Pro.

#### 1 PREPARE THE SURFACE

- All surfaces to be painted should be clean, dry and free from loose materials.
- Measure the area you wish to paint and clearly mark it using masking tape.
- Prime bare, untreated surfaces with Smart White Prime if required.
- Once primed, lightly sand the surface.

#### 2 APPLY THE BASE COAT (Light Green Paint)

- Stir paint thoroughly before use. If applying your paint to new plaster work apply one coat of standard white paint or primer then fill and sand smooth any defects.

##### Base Coats

- Apply your first coat of the base coat, using a mohair or lint free short pile roller sleeve.
- Sand smooth with sandpaper when dry and then apply the second base coat.
- Wait for paint to fully dry before applying the top coats of Smart Green Screen Paint Pro (approx. 2-4 hours at 20°).

##### Top Coats

- Ensure the base paint you have applied is smooth and free from surface defects.
- Apply the first top coat with a mohair or lint free short pile roller sleeve and allow to dry for (approx. 2-4 hours at 20°).
- Then apply the final coat of the Green Screen Paint Pro

#### 3 DRYING TIME

- Smart Green Screen Paint Pro will be touch-dry in 1 hour and usable after 12 hours.

### PRODUCT LIABILITY CLAUSE

The sale of our products is subject to our General Terms and Conditions available on [www.smartersurfaces.com](http://www.smartersurfaces.com)

### SUPPORT

 **EMAIL:**  
support@smartersurfaces.com

 **PHONE (IRE):**  
+353 1 412 6200

 **WEBSITE:**  
[www.smartersurfaces.com](http://www.smartersurfaces.com)