

SMART MAGNETIC PLASTER

APPLICATION GUIDE

Carefully measure the area you wish to cover and ensure you have enough paint.

To apply Smart Magnetic Plaster correctly, please follow the instructions below. Further information can be found on our website www.smartersurfaces.com.

HOW TO APPLY SMART MAGNETIC PLASTER



MEASURE

· Measure the area you wish to cover, ensuring you have a total of 2kg of magnetic plaster per 1 sq. metre (10.6 sq. feet)



PREPARE

- · Inspect your surface, making sure that it is clean, dry and capable of supporting the magnetic plaster. Cover any edges, light switches or fittings with masking tape. Apply a coat of Smart White Primer to seal the surface.
- · Ensure the primer is dry before applying Smart Magnetic Plaster



MIX

· Once you have opened your container of plaster, mix it well. Do not dilute as it is ready to use.



APPLY - COAT 1

- For professional installers, apply 1 kg per 1 sq. metre (10.6 sq. feet), or 1.2mm per coat, using a steel trowel.
- For non-professional installers, weigh out 1 kg of plaster on a scales. Apply this over an area of 1 sq. metre (10.6 sq. feet) with a plastering blade. Once applied, spread the plaster evenly across the area with a short pile roller sleeve. Repeat this process on the next 1 sq. metre area (10.6 sq. feet).



SMOOTH - COAT 1

Once your plaster has become partially dry, use a steel trowel to smooth the surface before it becomes fully dry. Afterwards, allow this coat a minimum of six hours drying time before applying the second coat.



APPLY - COAT 2

· Apply the second coat of plaster by repeating Step 4.



SMOOTH - COAT 2

Wait approximately one to two hours, or until your plaster has become partially dry. Then, using a steel trowel, smooth the surface before it has dried fully. If necessary, use a little water to dampen the surface when smoothing.

+353 1 412 6200

SUPPORT





SMART MAGNETIC PLASTER

APPLICATION GUIDE



INSPECT - THE SURFACE

Check if your surface is uneven or has any imperfections after the second coat of primer has dried. If so, apply a thin layer of plaster and lightly skim it over the surface with a smooth edged trowel to ensure an even. smooth finish.



ALLOW **DRYING** TIME AND **SAND** IF REQUIRED

Allow the surface to dry for a minimum of 24 hours. Once dry, lightly sand the surface as required.

YOUR WALL IS READY TO USE AS A MAGNETIC SURFACE OR AS A MAGNETIC BASE FOR THE FINISH OF YOUR CHOICE.

USING YOUR SMART MAGNETIC SURFACE

For best performance, we recommend using our Smart Neo-Magnets or any other high quality neodymium magnets available from your local Smarter Surfaces partner or from www.smartersurfaces.com.

PRODUCT LIABILITY CLAUSE

The sale of our products is subject to our General Terms and Conditions available on www.smartersurfaces.com

SUPPORT





